



VisionGuard
by Skyfol®

windshield film



Unlike regular polyester based windshield protection films, Skyfol **VisionGuard** is **super easy to install**. You do not need heat gun and lengthy heat shrinking procedures, just stretch onto the surface like a paint protection film and install in just minutes.

Skyfol VisionGuard has a PPF-like structure, enabling **outstanding protection** against rock chips and other mechanical impacts.

Unlike many other TPU based films, Skyfol VisionGuard offers **crystal clear** vision due to the special structure and premium grade adhesives used in the film construction. It comes with a **self healing coating**.



PLEASE ENSURE THAT ALL OF THE FOLLOWING STEPS HAVE BEEN FOLLOWED DURING INSTALLATION:

1. Wash the car using a high-pressure washer, paying special attention to the frames surrounding the windshield.

2. Remove any remaining contaminants from the glass using **C-Coat Clay Bar** and **C-COAT Clay Water**. If the polishing pad starts picking up contaminants, it will scratch the windshield throughout the polishing process.

3. Thoroughly rinse off the clay water and dry the surface using a **C-Coat Glass Towel**.

4. Completely remove grease stains and silicone residues from the glass using **C-Coat Glass Polish** and a polishing machine. This step is essential to avoid optical issues!

5. Wipe the glass and surrounding surfaces streak-free using **Organic Surface Cleaner**. Do not forget to clean the dirt under the rubber seals.

6. When cutting the film from the roll, ensure that the roll remains tight and does not loosen. Losing tension can lead to damage to the entire roll.

7. Lay the cut film on a clean table or a wet glass wall.

8. Remove the protective layer of the film while spraying it with the installation solution. We recommend using Johnson's baby shampoo mixed at a ratio of 1 liter of distilled water and at least 20 ml of shampoo for the installation. Then, turn the film over so that the liner can be removed later.

9. Thoroughly spray the windshield with the installation solution. Remove the liner while spraying the adhesive side of the film. Ensure there are no dry spots on either the glass or the adhesive side of the film!

10. Align the film to the windshield, then cut off any excess material.

11. If necessary, spray additional solution between the glass and the film.

12. For squeegeeing, use the **Skyfol Blue PPF Squeegee**. Avoid using overly hard squeegees, as they can easily damage the film. Remove all moisture from beneath the film.

13. Rinse out the solution along the edges using distilled water, as high-quality cutting can only be done on a stable film.

14. Wait a few minutes before starting the cutting process. Trim the film properly around the windshield.

15. After installation, apply **C-Coat Pro / Value ceramic coating** to the surface of the film. Wipe it off with a clean cloth 2-3 minutes later to ensure a streak-free finish. Clean the windshield wiper blades from contaminants as well, apply ceramic coating to the rubber using an applicator sponge, and allow it to dry thoroughly.

16. The water will completely dry out in 1-3 days, depending on climatic conditions.

17. For vehicle cleaning, use **C-Coat Graphene Shampoo**, which forms a hydrophobic layer that keeps the car shining at all times.

PLEASE CHECK OUR VIDEOS!
INSTALLATION GUIDE



PLEASE CHECK OUR VIDEOS!
ROLL HANDLING GUIDE





TECHNICAL FEATURES:

Thickness of the polyurethane film:	125 micron
Transmittance:	> 90 %
Haze:	< 1.0 %
UV Rejection:	> 99 %
Adhesion (30min.):	> 500 gf/25mm
Adhesion (24hours):	> 1000 gf/25mm

Adhesive:	Repositionable, non-yellowing, crystal-clear acrylic adhesive.
Resistance:	The film is resistant to general-use automotive fuels.
Warranty	1 year

The film is intended to offer surface protection. The film does not guarantee 100% protection against glass damage, it reduces the probability radically.

For the **installation and maintenance** of **VisionGuard**, we recommend using our professional products, which assist in surface preparation, professional installation, and proper maintenance. For more information about our products, please visit our website at www.skyfol.com.



C-COAT CERAMIC SEALANT

Sprayable sealant for an extremely hydrophobic, smooth, and glossy surface.



C-COAT GLASS POLISH

Polish paste for easy removal of grease stains and silicone residues from glass.



C-COAT GRAPHENE SHAMPOO

Powerful graphene-enriched concentrate for durable hydrophobic layer and enhanced protection of paintwork and film.



C-COAT VALUE

12 month coating for protection and easy cleaning



C-COAT PRO

36 month coating for protection and easy cleaning

C-COAT GLASS PAD

Polish pad for effective removal of grease stains and silicone residues from glass.

